

MAVProxy Cheatsheet (V 1.5.7)

Link

List all links link list
Set link n to primary set link N
Add new link link add X
Remove link link remove N

Map

Show waypoints wp list
Show fence fence list
Enable geofence fence enable
Disable geofence fence disable

Arming

Arm Vehicle arm throttle
Disarm Vehicle disarm
Force disarm (heli) disarm force

AUTO Flight

Set current wp wp set N
Engage auto mode auto
Override auto speed (m/s) setspeed N

Parameters

Get param value param show X
Set param param set X N
Download param defns param download
Get param help param help X

Flight modes

Loiter mode mode loiter
Return to Launch mode rtl

Manual mode mode manual
Fly to specific location mode guided
LAT LON ALT

Relays

Set relay relay set N [0|1]
Set output servo servo set N PWM

Terrain

Get terrain height at location terrain check
LAT LON